



RS STAND S3 V2

ASSEMBLY INSTRUCTIONS
RSEAT RS STAND S3 V2 32/65"TV


This instruction is developed to assist you in assembling
of RSEAT RS STAND S3 V2 for up to 65" TV's

Language: **EN**



2


Assemble the legs with the stand
as shown on the image.



Set the stand's height and
screw the fixation bolt

1

Assemble the legs as shown
on the picture.




⚠ WARNINGS

Before you begin assembling this tv stand,
please read all installation instructions
and warnings thoroughly.

**FAILURE TO COMPLY WITH OR OBSERVE ALL
ASSEMBLY, SAFETY AND OPERATION
INSTRUCTIONS AND WARNINGS REGARDING THE
USE OF THIS PRODUCT MAY RESULT IN SERIOUS
BODILY INJURY.**


This product complies with the prescribed
safety regulations. Inappropriate use may
cause damage to persons and tv stand.





3

Screw the vesa plates on your TV/Monitor and then attach the TV/Monitor on the stand. Adjust the angle of the TV.

IMPORTANT! Extend the bottom part of the vesa as much as possible before you install the TV on the stand.



After the tv is on the stand you can adjust the tilt and height of each vesa from this M8 screws. This helps to precise align the TV and lock it in place.



4

Lift the bottom part of the vesa to lock the TV/Monitor on place. Tighten the screws.

